

# 8028 configure with an OnSIP SIP server

## Get extension information from OnSIP

To start the process, you will need the following information:

Address of Record: [YYYYYYY@desertfuels.onsip.com](mailto:YYYYYYY@desertfuels.onsip.com)

SIP Password: 00000000000000

Auth Username: xxxxxxxxxxxx

Username: YYYYYYY

Proxy/Domain: xxxxxx.onsip.com

Proxy/Domain IP address of xxxxxx.onsip.com: 1111.2222.3333.4444

To find the Proxy/Domain IP address of xxxxxx.onsip.com open a Command Prompt on a Windows computer connected to Internet and write “ping xxxxxx.onsip.com” and click enter.

## Configure the Algo 8028

- 1) SIP Domain/Proxy = Proxy/Domain = xxxxxx.onsip.com
- 2) Outbound Proxy (optional) = Proxy/Domain IP address = 1111.2222.3333.4444
- 3) Extension = Username = YYYYYYY
- 4) Auth ID = Auth Username = xxxxxxxxxxxx
- 5) Password = SIP Password = 00000000000000
- 6) Dialing Extension = Extension to dial when the door station button is pushed.
- 7) Select “Double CRLF” under Keep-alive Method if your device is behind a NAT firewall.

| SIP                                       |   |
|---|---|
| <input type="checkbox"/> SIP Domain/Proxy | xxxxxxx.onsip.com   |
| Outbound Proxy (optional)                 | 1111.2222.3333.4444   |
| STUN Server (optional) ⓘ                  |   |
| Registrar (optional)                      |   |
| Register Period (seconds)                 | 3600  |
| Keep-alive Method                         | <input type="radio"/> None <input checked="" type="radio"/> Double CRLF |
| Keep-alive Period (seconds)               | 30  |
| <input type="checkbox"/> Extension        | YYYYYYY   |
| Auth ID                                   | xxxxxxxxxxx   |
| Password                                  | ●●●●●●●●●●●●●●●●  |
| Dialing Extension                         | 0000  |